



HUAWEI MC509 Series Mini PCIe Module

Hardware Guide

Issue 0.1

Date 2013-11-26

Huawei Technologies Co., Ltd. provides customers with comprehensive technical support and service. For any assistance, please contact our local office or company headquarters.

Huawei Technologies Co., Ltd.

Huawei Industrial Base, Bantian, Longgang, Shenzhen 518129, People's Republic of China

Tel: +86-755-28780808 Global Hotline: +86-755-28560808 Website: www.huawei.com

E-mail: mobile@huawei.com

Please refer color and shape to product. Huawei reserves the right to make changes or improvements to any of the products without prior notice.

Copyright © Huawei Technologies Co., Ltd. 2013. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd..

The product described in this manual may include copyrighted software of Huawei Technologies Co., Ltd. and possible licensors. Customers shall not in any manner reproduce, distribute, modify, decompile, disassemble, decrypt, extract, reverse engineer, lease, assign, or sublicense the said software, unless such restrictions are prohibited by applicable laws or such actions are approved by respective copyright holders under licenses.

Trademarks and Permissions

HUAWEI, HUAWEI, and are trademarks or registered trademarks of Huawei Technologies Co., Ltd..

Other trademarks, product, service and company names mentioned are the property of their respective owners.

Notice

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and may not be activated or may be limited by local network operators or network service providers, thus the descriptions herein may not exactly match the product or its accessories you purchase.

Huawei Technologies Co., Ltd. reserves the right to change or modify any information or specifications contained in this manual without prior notice or obligation.

NO WARRANTY

THE CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO CASE SHALL HUAWEI TECHNOLOGIES CO., LTD. BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOST PROFITS, BUSINESS, REVENUE, DATA, GOODWILL OR ANTICIPATED SAVINGS.

Import and Export Regulations


Customers shall comply with all applicable export or import laws and regulations and will obtain all necessary governmental permits and licenses in order to export, re-export or import the product mentioned in this manual including the software and technical data therein.



About This Document

Revision History

Document Version	Date	Chapter	Descriptions
0.1	2013-11-26		Creation This is a draft version, and some chapters are still with "TBD".





Contents

1 Introduction	7
2 Overall Description	8
2.1 About This Chapter	8
2.2 Function Overview	8
2.3 Circuit Block Diagram	9
3 Description of the Application Interfaces	10
3.1 About This Chapter	
3.2 Mini PCle Interface	
3.3 Power Sources and Grounds	
3.4 Power Supply Time Sequence	15
3.5 WAKE# Signal	
3.6 RESIN_N Signal	16
3.7 W_DISABLE# Signal	18
3.8 LED_WWAN# Signal	18
3.9 USB Interface	19
3.10 RUIM Card Interface	20
3.10.1 Overview	20
3.10.2 Circuit Recommended for the RUIM Card Interface	
3.11 Audio Interface	21
3.12 RF Antenna Connector	22
3.13 Reserved Pins	23
3.14 NC Pins	23
4 RF Specifications	25
4.1 About This Chapter	25
4.2 Operating Frequencies	25
4.3 Conducted RF Measurement	26
4.3.1 Test Environment	26
4.3.2 Test Standards	26
4.4 Conducted Rx Sensitivity and Tx Power	26
4.4.1 Conducted Receive Sensitivity	26
4.4.2 Conducted Transmit Power	28
4.5 Antenna Design Requirements	28

4.5.1 Antenna Design Indicators	28
4.5.2 Interference	
4.5.3 CDMA Antenna Requirements	31
4.5.4 Radio Test Environment	31
5 Electrical and Reliability Features	33
5.1 About This Chapter	33
5.2 Absolute Ratings	33
5.3 Operating and Storage Temperatures	34
5.4 Electrical Features of RUIM	34
5.5 Electrical Features of Application Interfaces	34
5.6 Power Supply Features	35
5.6.1 Input Power Supply	35
5.6.2 Power Consumption	35
5.7 Reliability Features	36
5.8 EMC and ESD Features	39
6 Mechanical Specifications	41
6.1 About This Chapter	41
6.2 Dimensions and Interfaces	41
6.3 Dimensions of the Mini PCI Express Connector	42
6.4 Specification Selection for Fasteners	43
6.4.1 Installing the Mini PCIe Adapter on the Main Board	43
6.4.2 Removing the Mini PCIe Adapter from the Main Board	45
6.5 Antenna Plug	
6.6 Thermal Design Guide	47
7 Certifications	49
7.1 About This Chapter	49
7.2 Certifications	49
8 Safety Information	50
8.1 Interference	
8.2 Medical Device	
8.3 Area with Inflammables and Explosives	50
8.4 Traffic Security	
8.5 Airline Security	
8.6 Safety of Children	51
8.7 Environment Protection	51
8.8 WEEE Approval	51
8.9 RoHS Approval	
8.10 Laws and Regulations Observance	
8.11 Care and Maintenance	
8.12 Emergency Call	52

HUAWEI MC509 Series Mini PCIe Module Hardware Guide

Contents

8.13 Regulatory Information	52
8.13.1 CE Approval (European Union)	
8.13.2 FCC Statement	53
9 Appendix A Circuit of Typical Interface	54
10 Appendix B Acronyms and Abbreviations	55





1 Introduction

This document describes the hardware application interfaces and air interfaces provided by HUAWEI MC509 Series Mini PCle Module, including MC509-a and MC509 (hereinafter referred to as the MC509 module).

This document helps hardware engineer to understand the interface specifications, electrical features and related product information of the MC509 module.

Table 1-1 MC509 series product name

Product name	Description	State
MC509-a	CDMA/EVDO 800 MHz GPS	Under development
MC509	CDMA/EVDO 1900 MHz/800 MHz GPS	Planning



2 Overall Description

2.1 About This Chapter

This chapter gives a general description of the MC509 module and provides:

- Function Overview
- Circuit Block Diagram

2.2 Function Overview

Table 2-1 Features

Feature	Description				
Physical Dimensions	 Dimensions (L × W × H): 50.95 mm × 30.4 mm × 3.57 mm Weight: about 12 g 				
Operating Temperature	-20°C to +60°C				
Storage Temperature	-40°C to +85°C				
Power Voltage	DC 3.0 V–3.6 V (typical value is 3.3 V)				
Application Interface	One standard Removable User Identity Module (RUIM) card (3 V or 1.8 V)				
(52-pin Mini PCle interface	Audio interface: PCM interface				
	USB 2.0 (Full Speed)				
	RESIN_N: Reset module				
	WAKE#: Wake up signal				
	W_DISABLE# Signal				


Feature	Description
	LED_WWAN#: Active-low LED signal indicating the state of the module
Antenna connector	WWAN MAIN antenna connector x1 WWAN AUX antenna connector x1 GPS antenna connector x1

2.3 Circuit Block Diagram

Figure 2-1 shows the circuit block diagram of the MC509 Mini PCIe Adapter. The major functional unit of the Mini PCIe Adapter contains the following parts:

- DCDC Circuit
- LGA Module
- Control signals
- Antenna Connectors

Figure 2-1 Circuit block diagram of the MC509 module





3

Description of the Application Interfaces

3.1 About This Chapter

This chapter mainly describes the external application interfaces of the MC509 module, including:


- Mini PCle Interface
- Power Sources and Grounds
- Power Supply Time Sequence
- WAKE# Signal
- RESIN N Signal
- W DISABLE# Signal
- LED WWAN# Signal
- USB Interface
- RUIM Card Interface
- Audio Interface
- RF Antenna Connector
- Reserved Pins
- NC Pins

3.2 Mini PCIe Interface

The MC509 module uses a Mini-PCle interface as its external interface. For details about the module and dimensions, see "6.2 Dimensions and Interfaces".



Figure 3-1 shows the sequence of pins on the interface of the Mini PCIe Adapter.






Table 3-1 shows the pin definitions of the Mini PCle Interface.

Table 3-1 Pin definitions of the Mini PCle interface

PIN	Pin Name		I/O Description		DC Characteristics (V)		
No.	Mini PCI Express Standard Description	HUAWEI Pin Description			Min.	Тур.	Max.
1	WAKE#	WAKE#	0	Open collector active low signal. This signal is used to wake up the host.	-0.3	-	-
2	3.3Vaux	VCC_3V3	Р	3.3 V DC supply rails from the PC side.	3.0	3.3	3.6
3	COEX1	NC	-	Not connected	-	-	-
4	GND	GND	-	Ground	-	-	-
5	COEX2	NC	-	Not connected	-	-	-
6	1.5 V	NC	-	Not connected	-	-	-



PIN	Pin Name		I/O	Description	DC Cha	racteristics	(V)
No.	Mini PCI Express Standard Description	HUAWEI Pin Description			Min.	Тур.	Max.
7	CLKREQ#	NC	-	Not connected	-	-	-
8	UIM_PWR	RUIM_PWR	Р	Power source for the external RUIM card	-	1.8/2.85	-
9	GND	GND	-	Ground	-	-	-
10	UIM_DATA	RUIM_DATA	I/O	External RUIM data signal	-	1.8/2.85	-
11	REFCLK-	NC	-	Not connected	-	-	-
12	UIM_CLK	RUIM_CLK	0	External RUIM clock signal	-	1.8/2.85	-
13	REFCLK+	NC	-	Not connected		-	-
14	UIM_RESET	RUIM_RESET	0	External RUIM reset signal	-	1.8/2.85	-
15	GND	GND		Ground	-	-	-
16	UIM_Vpp	NC	-	Not connected	-	-	-
17	Reserved	Reserved	-	Reserved	-	-	-
18	GND	GND	-	Ground	-	-	-
19	Reserved	Reserved	-	Reserved	-	-	-
20	W_DISABLE#	W_DISABLE#		The W_DISABLE# signal is an active low signal that when asserted (driven low) by the system shall disable radio operation.	-	-	-
21	GND	GND	-	Ground	-	-	-
22	PERST#	RESIN_N	I	Reset module Active-low	-	-	-
23	PERn0	NC	-	Not connected	-	-	-
24	3.3Vaux	VCC_3V3	Р	3.3 V DC supply rails from the PC side.	3.0	3.3	3.6
25	PERp0	NC	-	Not connected	-	-	-
26	GND	GND	-	Ground	-	-	-



PIN			I/O	Description	on DC Characteristics		
No.	Mini PCI Express Standard Description	HUAWEI Pin Description			Min.	Тур.	Max.
27	GND	GND	-	Ground	-	-	-
28	1.5 V	NC	-	Not connected	-	-	-
29	GND	GND	-	Ground	-	-	-
30	SMB_CLK	NC	-	Not connected	-	-	-
31	PETn0	NC	-	Not connected	-	-	-
32	SMB_DATA	NC	-	Not connected	-	-	-
33	PETp0	NC	-	Not connected	-	-	-
34	GND	GND	-	Ground	-	-	-
35	GND	GND	-	Ground	-	-	-
36	USB_D-	USB_DM	I/O	USB signal D-	-	-	-
37	GND	GND	-	Ground		-	-
38	USB_D+	USB_DP	1/0	USB signal D+	-	-	-
39	3.3Vaux	VCC_3V3	Р	3.3 V DC supply rails from the PC side.	3.0	3.3	3.6
40	GND	GND	-	Ground	-	-	-
41	3.3Vaux	VCC_3V3	Р	3.3 V DC supply rails from the PC side	3.0	3.3	3.6
42	LED_WWAN#	LED_WWAN#	0	Active-low LED signal indicating the state of the card. SINK current source Drive strength: 10 mA	-	-	-
43	GND	GND	-	Ground	-	-	-
44	LED_WLAN#	NC	-	Not connected	-	-	-
45	Reserved	PCM_CLK	0	PCM interface clock	-0.3	2.6	2.9
46	LED_WPAN#	NC	-	Not connected	-	-	-
47	Reserved	PCM_DOUT	0	PCM I/F data out	-0.3	2.6	2.9
48	1.5 V	NC	-	Not connected	-	-	-



PIN	Pin Name		I/O Description		DC Characteristics (V)		
No.	Mini PCI Express Standard Description	HUAWEI Pin Description			Min.	Тур.	Max.
49	Reserved	PCM_DIN	I	PCM I/F data in	-0.3	2.6	2.9
50	GND	GND	-	Ground	-	-	-
51	Reserved	PCM_SYNC	0	PCM interface sync	-0.3	2.6	2.9
52	3.3Vaux	VCC_3V3	Р	3.3 V DC supply rail from the PC side.	3.0	3.3	3.6

☐ NOTE

- P indicates power pins; I indicates pins for digital signal input; O indicates pins for digital signal output. Al indicates pins for analog signal input.
- The **Reserved** pins are internally connected to the module. Therefore, these pins should not be used, otherwise they may cause problems. Please contact with us for more details about this information.
- The **NC** (Not Connected) pins are floating and there are no signal connected to these pins. Therefore, these pins should not be used.

3.3 Power Sources and Grounds

For the Mini PCle Adapter, +3.3 Vaux is the only voltage supply that is available. The input voltage is 3.3 V±9%, as specified by *PCl Express Mini CEM Specifications 1.2.*

Table 3-2 Power and ground specifications

Pin No.	Pin Name	Minimum	Typical	Maximum
2, 24, 39, 41 and 52	VCC_3V3	3.0 V	3.3 V	3.6 V
4, 9, 15, 18, 21, 26, 27, 29, 34, 35, 37, 40, 43, and 50	GND	-		

□ NOTE

To minimize the RF radiation through the power lines, it is suggested to add ceramic capacitors of 10 pF and 100 nF in the power lines beside the Mini PCle connector on the host side.




3.4 Power Supply Time Sequence

Power on sequence

Do not toggle RESIN_N pin during the power on sequence. Pulling RESIN_N pin low will extend time for module startup.

Figure 3-2 Power on timing sequence




Parameter	Remarks	Time (Nominal value)	Unit
T _{PD+}	Power Valid to USB D+ high	about 4	s

Power off Sequence

Cutting off 3.3 V will power off the module.

Figure 3-3 Power off timing sequence





3.5 WAKE# Signal

WAKE# pin (the signal that the module uses to wake up the PC) supports software control.

This signal is used for module to wake up the host. It is designed as an OC gate, so it should be pulled up by the host and it is active-low.

When the module wakes up the host, the WAKE# pin will output low-level-voltage to wake the host.





Figure 3-4 Connections of the WAKE# pin



3.6 RESIN_N Signal

The RESIN_N pin is used to reset the module's system. When the module software stops responding, the RESIN_N pin can be pulled down to reset the module hardware.

The RESIN_N signal is internally pulled up to 1.8 V, which is automatically on when 3.3 V is applied and it is active-low.




Figure 3-5 Connections of the RESIN N pin




CAUTION

- As the RESIN_N signal are relatively sensitive, it is recommended that you install a 10 nF to 0.1 μF capacitor near the RESIN_N pin of the interface for filtering. In addition, when you design a circuit on the PCB of the interface board, it is recommended that the circuit length should not exceed 20 mm and that the circuit should be kept at a distance of 2.54 mm (100 mil) at least from the PCB edge. Furthermore, you need to wrap the area adjacent to the signal wire with a ground wire. Otherwise, the module may be reset due to interference.
- The maximum Forward Voltage Drop of the diode used in the module is 0.6 V. So
 when the host wants to reset the module, the low-level-voltage in the RESIN_N pin
 should below 50 mV.

The MC509 module supports hardware reset function. If the software of the MC509 module stops responding, you can reset the hardware through the RESIN_N signal as shown in Figure 3-6. When a low-level pulse is supplied through the RESIN_N pin, the hardware will be reset. After the hardware is reset, the software starts powering on the module and reports relevant information according to the actual settings. For example, the AT command automatically reports ^SYSSTART.

Figure 3-6 Reset pulse timing



MOTE

- The RESIN N pin must not be pulled down for more than 1s.
- The RESIN N pin is optional, which can be not connected.
- The maximum Forward Voltage Drop of the diode used in the module is 0.6 V.




3.7 W_DISABLE# Signal

The W_DISABLE# signal is provided to allow users to disable wireless communications of the module.

The W_DISABLE# signal is internally pulled up, which is automatically on when 3.3 V is applied and it is active-low.

Figure 3-7 Connections of the W DISABLE# pin



∭ NOTE

- As the W_DISABLE# signal are relatively sensitive, it is recommended that you install a 10 nF to 0.1 μF capacitor near the W_DISABLE# pin of the interface for filtering.
- The maximum Forward Voltage Drop of the diode used in the module is 0.6 V. So when the
 host wants to reset the module, the low-level-voltage in the W_DISABLE# pin should below
 50 mV.

3.8 LED_WWAN# Signal

MC509 provides a LED WWAN# signal to indicate the RF status.


The pulse signal output through this pin controls the status LED on the user interface board to display the network status. The LEDs are controlled by a current sink. The high voltage is the voltage of VCC (with the typical value of 3.3 V). The planning drive strength is 10 mA.

External Circuits

Figure 3-8 shows the recommended circuits of the LED_WWAN# pin. According to LED feature, you can adjust the LED brightness by adjusting the resistance of resistor R.



Figure 3-8 Driving circuit



3.9 USB Interface

The MC509 module is compliant with USB 2.0 protocol. The USB interface is powered directly from the VBAT supply. The USB input/output lines are compatible with the USB 2.0 signal specifications. Figure 3-9 shows the circuit of the USB interface.

Table 3-3 Definition of the USB interface

Pin No.	Pin Name	I/O	Description	DC CI	naracteristic	s (V)
				Min.	Тур.	Max.
36	USB_DM	I/O	USB signal D-	-	-	-
38	USB_DP	I/O	USB signal D+	-	-	-

According to USB protocol, for bus timing or electrical characteristics of MC509 USB signal, please refer to the chapter 7.3.2 of *Universal Serial Bus Specification 2.0*.




Figure 3-9 Recommended circuit of USB interface

3.10 RUIM Card Interface

3.10.1 Overview

The MC509 module provides a RUIM card interface complying with the C.S0023 standard and supports automatic detection of a 3.0 V RUIM card or a 1.8 V RUIM card.

Table 3-4 RUIM card interface signals

Pin	Pin Name	I/O	Description	DC Ch	aracteristics	(V)
No.				Min.	Тур.	Max.
14	RUIM_RESET	0	External RUIM reset signal.	-	1.8/2.85	-
12	RUIM_CLK	0	External RUIM clock signal	-	1.8/2.85	-
10	RUIM_DATA	I/O	External RUIM data signal	-	1.8/2.85	-
8	RUIM_PWR	Р	Power source for the external RUIM card	-	1.8/2.85	-

3.10.2 Circuit Recommended for the RUIM Card Interface

As the Mini PCIe Adapter is not equipped with an RUIM socket, you need to place an RUIM socket on the user interface board.

Figure 3-10 shows the circuit of the RUIM card interface.




Figure 3-10 Circuit of the RUIM card interface



CAUTION

- To meet the requirements of 3GPP TS 11.11protocols and electromagnetic compatibility (EMC) authentication, the RUIM socket should be placed near the PCIe interface (it is recommended that the PCB circuit connects the PCIe interface and the RUIM socket does not exceed 100 mm), because a long circuit may lead to wave distortion, thus affecting signal quality.
- It is recommended that you wrap the area adjacent to the RUIM_CLK and RUIM_DATA signal wires with ground. The Ground pin of the RUIM socket and the Ground pin of the RUIM card must be well connected to the power Ground pin supplying power to the PCIe Adapter.
- A 100 nF capacitor and 1 μF capacitor are placed between the RUIM_PWR and GND pins in a parallel manner (If RUIM_PWR circuit is too long, that the larger capacitance such as 4.7 μF can be employed if necessary). Three 33 pF capacitors are placed between the RUIM_DATA and Ground pins, the RUIM_RESET and Ground pins, and the RUIM_CLK and Ground pins in parallel to filter interference from RF signals.
- It is recommended to take electrostatic discharge (ESD) protection measures near the RUIM card socket. The TVS diode with Vrwm of 5 V and junction capacitance less than 10 pF must be placed as close as possible to the RUIM socket, and the Ground pin of the ESD protection component is well connected to the power Ground pin that supplies power to the PCIe Adapter.
- It is not recommended that pull the RUIM_DATA pin up during design as a 15000-ohm resistor is used to connect the RUIM_DATA pin to the RUIM_VCC.

3.11 Audio Interface

The MC509 module provides one PCM digital audio interface. Table 3-5 lists the signals on the digital audio interface.




Pin	Pin Name	I/O	Description	DC Char	acteristics	(V)
No.				Min.	Typ.	Max.
45	PCM_CLK	0	PCM clock	-0.3	2.6	2.9
49	PCM_DIN	I	PCM data input	-0.3	2.6	2.9
51	PCM_SYNC	0	PCM interface sync	-0.3	2.6	2.9
47	PCM_DOUT	0	PCM data output	-0.3	2.6	2.9

Table 3-5 Signals on the digital audio interface

The MC509 PCM interface enables communication with an external codec to support linear and μ-law format. The PCM_SYNC runs at 8 kHz with a 50% duty cycle.

Figure 3-11 Circuit diagram of the interface of the PCM (MC509 module is used as PCM master)



- PCM_SYNC: Output when PCM is in master mode;
- PCM CLK: Output when PCM is in master mode;
- The PCM function of MC509 only supports master mode;
- It is recommended that a TVS be used on the related interface, to prevent electrostatic discharge and protect integrated circuit (IC) components.

3.12 RF Antenna Connector

The MC509 module provides three antenna connectors (MAIN, GPS and AUX) for connecting the external antennas.

AUX GPS MAIN

Figure 3-12 RF antenna connectors

The antenna connectors must be used with coaxial cables with characteristic impedance of 50 Ω .

3.13 Reserved Pins

The MC509 module provides 2 reserved pins. All of reserved pins cannot be used by the customer.

Table 3-6 Reserved pins

Pin No.	Pin Name	I/O	Description
17, 19	Reserved	-	Reserved, please keep open.

3.14 NC Pins

The MC509 module has 17 NC pins. All of NC pins should not be connected. Please keep these pins open.



Table 3-7 NC pins

Pin No.	Pin Name	I/O	Description
3, 5–7, 11, 13, 16, 23, 25, 28, 30–33, 44, 46, 48	NC	-	Not connected, please keep open.





4 RF Specifications

4.1 About This Chapter

This chapter describes the RF specifications of the MC509 series module, including:

- Operating Frequencies
- Conducted RF Measurement
- Conducted Rx Sensitivity and Tx Power
- MC509 module conducted Tx power (unit: dBm)

Item	MC509 Te	est Value (dBm)	
	Min.	Тур.	Max.
BC0(CDMA 800 MHz)	23	TBD	25
BC1(CDMA 1900 MHz)	23	TBD	25

Antenna Design Requirements

4.2 Operating Frequencies

Table 4-1 Table 4-2 shows the RF bands supported by the MC509-a and MC509 module.

Table 4-1 RF bands of MC509-a

Operating Band	Tx	Rx
CDMA 800 (BC0)	824 MHz-849MHz	869 MHz-894 MHz
GPS	NA	1574.42 MHz-1576.42 MHz



Table 4-2 RF bands of MC509

Operating Band	Tx	Rx
CDMA 800 (BC0)	824 MHz-849MHz	869 MHz-894 MHz
CDMA 1900 (BC1)	1850 MHz-1910MHz	1930 MHz–1990 MHz
GPS	NA	1574.42 MHz-1576.42 MHz

4.3 Conducted RF Measurement

4.3.1 Test Environment

Test instrument R&S CMU200, Agilent 8960

Power supply Keithley 2303, Agilent 66319

RF cable for testing L08-C014-350 of DRAKA COMTEQ or Rosenberger

Cable length: 29 cm



- The compensation for different frequency bands relates to the cable and the test environment.
- The instrument compensation needs to be set according to the actual cable conditions.

4.3.2 Test Standards

Huawei modules meet all 3GPP2 test standards relating to 3G. Each module passes strict tests at the factory and thus the quality of the modules is guaranteed.

4.4 Conducted Rx Sensitivity and Tx Power

4.4.1 Conducted Receive Sensitivity

The conducted receive sensitivity is a key parameter that indicates the receiver performance of MC509 series module. The conducted receive sensitivity refers to the weakest signal that the module at the antenna port can receive. The BER must meet the 3GPP protocol requirements in the case of the minimum signal.

Table 4-3 and Table 4-4 lists the typical tested values of the MC509-a module and MC509 module.



Table 4-3 MC509-a module conducted Rx sensitivity (Unit: dBm)

Item		3GPP2 Protocol	MC509-a Test Value (dBm)			
TCM.	icii		Min.	Тур.	Max.	
CDMA 800	1x(FER < 0.5%)	< -104	-	-107	-104	
Primary	EVDO(PER < 0.5%)	< -105.5	-	-109	-105.5	
CDMA 800	1x(FER < 0.5%)	-	-	-106	-	
Diversity	EVDO (PER < 0.5%)	-	-	-107	-	

Table 4-4 MC509 module conducted Rx sensitivity (Unit: dBm)

Item		3GPP2	MC509 Test Value (dBm)			
		Protocol Claim (dBm)	Min.	Тур.	Max.	
CDMA 800	1x(FER<0.5%)	<-104	-	TBD	TBD	
Primary	EVDO(PER<0.5%)	< -105.5	-	TBD	TBD	
CDMA1900	1x(FER<0.5%)	< -104	-	TBD	TBD	
Primary	EVDO(PER<0.5%)	< -105.5	-	TBD	TBD	
CDMA 800	1x(FER<0.5%)	-	-	TBD	-	
Diversity	EVDO(PER<0.5%)	-	-	TBD	-	
CDMA1900	1x(FER<0.5%)	-	-	TBD	-	
Diversity	EVDO(PER<0.5%)	-	-	TBD	-	

Table 4-5 MC509 series module GPS main characteristics

Item	Type Value
Receive Sensitivity (Cold start)	TBD
Receive Sensitivity (Hot start)	TBD
Receive Sensitivity (Tracking mode)	TBD
TTFF@-130dBm (Cold start)	TBD
TTFF@-130dBm (Hot start)	TBD

 \square NOTE

The test values are the average of some test samples.



4.4.2 Conducted Transmit Power

The conducted transmit power is another indicator that measures the performance of MC509 series module. The conducted transmit power refers to the maximum power that the module tested at the antenna connector can transmit. According to the 3GPP2 protocol, the required transmit power varies with the power class.

Table 4-6 Table 4-7lists the typical tested values of the MC509-a module and MC509 module.

Table 4-6 MC509-a module conducted Tx power (unit: dBm)

Item	MC509-a Test Value (dBm)		
	Min. Typ. Max.		
BC0(CDMA 800 MHz)	23	TBD	25

Table 4-7 MC509 module conducted Tx power (unit: dBm)

Item	MC509 Test Value (dBm)			
	Min.	Тур.	Max.	
BC0(CDMA 800 MHz)	23	TBD	25	
BC1(CDMA 1900 MHz)	23	TBD	25	

4.5 Antenna Design Requirements

4.5.1 Antenna Design Indicators

Antenna Efficiency

Antenna efficiency is the ratio of the input power to the radiated or received power of an antenna. The radiated power of an antenna is always lower than the input power due to the following antenna losses: return loss, material loss, and coupling loss. The efficiency of an antenna relates to its electrical dimensions. To be specific, the antenna efficiency increases with the electrical dimensions. In addition, the transmission cable from the antenna connector of PCIe Adapter to the antenna is also part of the antenna. The cable loss increases with the cable length and the frequency. It is recommended that the cable loss is as low as possible, for example, MXHP32HP1000 made by Murata or equivalent.

The following antenna efficiency (free space) is recommended for MC509 module to ensure high radio performance of the module:

Efficiency of the primary antenna: ≥ 40% (below 960 MHz); ≥ 50% (over 1710 MHz)



- Efficiency of the diversity antenna: ≥ half of the efficiency of the primary antenna in receiving band
- Efficiency of the GPS antenna: ≥ 50%

In addition, the efficiency should be tested with the transmission cable.

S11 or VSWR

S11 indicates the degree to which the input impedance of an antenna matches the reference impedance (50 Ω). S11 shows the resonance feature and impedance bandwidth of an antenna. Voltage standing wave ratio (VSWR) is another expression of S11. S11 relates to the antenna efficiency. S11 can be measured with a vector analyzer.

The following S11 value is recommended for the antenna of MC509 module:

- S11 of the primary antenna: ≤ –6 dB
- S11 of the diversity antenna: ≤ -6 dB
- S11 of the GPS antenna: ≤ –10 dB

In addition, S11 is less important than the efficiency, and S11 has weak correlation to wireless performance.

Isolation

For a wireless device with multiple antennas, the power of different antennas is coupled with each other. Antenna isolation is used to measure the power coupling. The power radiated by an antenna might be received by an adjacent antenna, which decreases the antenna radiation efficiency and affects the running of other devices. To avoid this problem, evaluate the antenna isolation as sufficiently as possible at the early stage of antenna design.

Antenna isolation depends on the following factors:

- Distance between antennas
- Antenna type
- Antenna direction

The primary antenna must be placed as near as possible to the MC509 module to minimize the cable length. The diversity antenna needs to be installed perpendicularly to the primary antenna. The diversity antenna can be placed farther away from the MC509 module. Antenna isolation can be measured with a two-port vector network analyzer.

The following antenna isolation is recommended for the antennas on laptops:

- Isolation between the primary and diversity antennas: ≤ -12 dB
- Isolation between the primary(diversity) antenna and the GPS antenna: ≤
 -15 dB
- Isolation between the primary antenna and the Wi-Fi antenna: ≤ -15 dB

Polarization

The polarization of an antenna is the orientation of the electric field vector that rotates with time in the direction of maximum radiation.

RF Specifications



The linear polarization is recommended for the antenna of MC509 module.

Radiation Pattern

The radiation pattern of an antenna reflects the radiation features of the antenna in the remote field region. The radiation pattern of an antenna commonly describes the power or field strength of the radiated electromagnetic waves in various directions from the antenna. The power or field strength varies with the angular coordinates (θ and ϕ), but is independent of the radial coordinates.

The radiation pattern of half wave dipole antennas is omnidirectional in the horizontal plane, and the incident waves of base stations are often in the horizontal plane. For this reason, the receiving performance is optimal.

The following radiation patterns are recommended for the antenna of MC509 module.

Primary/Diversity/GPS antenna: omnidirectional

In addition, the diversity antenna's pattern should be complementary with the primary's.

Envelope Correlation Coefficient

The envelope correlation coefficient indicates the correlation between different antennas in a multi-antenna system (primary antenna, diversity antenna, and MIMO antenna). The correlation coefficient shows the similarity of radiation patterns, that is, amplitude and phase, of the antennas. The ideal correlation coefficient of a diversity antenna system or a MIMO antenna system is 0. A small value of the envelope correlation coefficient between the primary antenna and the diversity antenna indicates a high diversity gain. The envelope correlation coefficient depends on the following factors:

- Distance between antennas
- Antenna type
- Antenna direction

The antenna correlation coefficient differs from the antenna isolation. Sufficient antenna isolation does not represent a satisfactory correlation coefficient. For this reason, the two indicators need to be evaluated separately.

For the antennas on laptops, the recommended envelope correlation coefficient between the primary antenna and the diversity antenna is smaller than 0.5.

Gain and Directivity

The radiation pattern of an antenna represents the field strength of the radiated electromagnetic waves in all directions, but not the power density that the antenna radiates in the specific direction. The directivity of an antenna, however, measures the power density that the antenna radiates.

Gain, as another important parameter of antennas, correlates closely to the directivity. The gain of an antenna takes both the directivity and the efficiency of the antenna into account. The appropriate antenna gain prolongs the service life of relevant batteries.

The following antenna gain is recommended for MC509 module. **Gain of the primary/diversity antenna ≤ 2.5 dBi**



Ⅲ NOTE

- The antenna consists of the antenna body and the relevant RF transmission cable. Take the RF transmission cable into account when measuring any of the preceding antenna indicators.
- Huawei cooperates with various famous antenna suppliers who are able to make suggestions on antenna design, for example, Amphenol, Skycross, etc.

4.5.2 Interference

Besides the antenna performance, the interference on the user board also affects the radio performance (especially the TIS) of the module. To guarantee high performance of the module, the interference sources on the user board must be properly controlled.

On the user board, there are various interference sources, such as the LCD, CPU, audio circuits, and power supply. All the interference sources emit interference signals that affect the normal operation of the module. For example, the module sensitivity can be decreased due to interference signals. Therefore, during the design, you need to consider how to reduce the effects of interference sources on the module. You can take the following measures: Use an LCD with optimized performance; shield the LCD interference signals; shield the signal cable of the board; or design filter circuits.

Huawei is able to make technical suggestions on radio performance improvement of the module.

4.5.3 CDMA Antenna Requirements

The antenna for MC509 series module must fulfill the following requirements:

CDMA Antenna Requir	CDMA Antenna Requirements			
Frequency range	Depending on frequency band (s)provided by the network operator, the customer must use the most suitable antenna for that/those band (s)			
Bandwidth	70 MHz in CDMA800 (25 MHz for diversity antenna) 140 MHz in CDMA1900 (60 MHz for diversity antenna)			
Gain	Gain ≤ 2.5 dBi			
Impedance	50-ohm			
VSWR absolute max	≤ 3:1 (≤ 2:1 for GPS antenna)			
VSWR recommended	≤ 2:1 (≤ 1.5:1 for GPS antenna)			

4.5.4 Radio Test Environment

The antenna efficiency, antenna gain, radiation pattern, total radiated power (TRP), and TIS can be tested in a microwave testing chamber.

Huawei has a complete set of OTA test environments (SATIMO microwave testing chambers and ETS microwave testing chambers). The testing chambers are certified



by professional organizations and are applicable to testing at frequencies ranging from 380 MHz to 6 GHz. The test items are described as follows:

Passive Tests


- Antenna efficiency
- Gain
- Pattern shape
- Envelope correlation coefficient

Active Tests

- TRP: GSM, WCDMA, CDMA, TD-SCDMA, and LTE systems
- TIS: GSM, WCDMA, CDMA, TD-SCDMA, and LTE systems

Figure 4-1 shows the SATIMO microwave testing chamber.

Figure 4-1 SATIMO microwave testing chamber





5

Electrical and Reliability Features

5.1 About This Chapter

This chapter describes the electrical and reliability features of the interfaces in the MC509 series module, including:

- Absolute Ratings
- Operating and Storage Temperatures
- Electrical Features of RUIM
- Power Supply Features
- Reliability Features
- EMC and ESD Features

5.2 Absolute Ratings



WARNING

Table 5-1 lists the absolute ratings for the MC509 series module. Using the module beyond these conditions may result in permanent damage to the module.

Table 5-1 Absolute ratings for the MC509 series module

Symbol	Specification	Min.	Max.	Unit
VCC_3V3	External power voltage	-0.3	4.0	V
VI	Digital input voltage	-0.4	3.3	٧



5.3 Operating and Storage Temperatures

Table 5-2 lists the operating and storage temperatures for the MC509 series module.

Table 5-2 Operating and storage temperatures for the MC509 series module

Specification	Min.	Max.	Unit
Normal working temperatures ^[1]	-20	+60	°C
Ambient temperature for storage	-40	+85	°C

NOTE

[1]: When the MC509 module works at this temperature, all its RF indexes comply with the 3GPP2 C.S057D specifications.

5.4 Electrical Features of RUIM

Table 5-3 Electrical features of Digital Pins in the I/O supply domain of the RUIM Interface

Parameter	Description	Minimum Value	Maximum Value	Unit
V _{IH}	Logic high-level input voltage	0.65 x V _{DD_PX}	V _{DD_PX} + 0.3	V
VIL	Logic low-level input voltage	-0.3	0.35 x V _{DD_PX}	V
V _{OH}	Logic high-level output voltage	V _{DD_PX} -0.45	V_{DD_PX}	V
V _{OL}	Logic low-level output voltage	0	0.45	V

5.5 Electrical Features of Application Interfaces

Table 5-4 lists electrical features (typical values).

Table 5-4 Electrical features of application interfaces

Parameter	Description	Minimum Value	Maximum Value	Unit
V _{IH}	Logic high-level input voltage	0.65 x V _{DD_PX}	V _{DD_PX} + 0.3	V

Parameter	Description	Minimum Value	Maximum Value	Unit
V _{IL}	Logic low-level input voltage	-0.3	0.35 x V _{DD_PX}	V
V _{OH}	Logic high-level output voltage	V _{DD_PX} -0.45	V_{DD_PX}	V
V _{OL}	Logic low-level output voltage	0	0.45	V

5.6 Power Supply Features

5.6.1 Input Power Supply

Table 5-5 lists the requirements for input power of the MC509 series module.

Table 5-5 Requirements for input power for the MC509 series module

Parameter	Min.	Тур.	Max.	Ripple	Unit
VCC_3V3	3.0	3.3	3.6	0.05	V

Figure 5-1 Power Supply During Burst Emission




Table 5-6 Requirements for input current of the MC509 series module

Power	Module	Peak	Normal
VCC_3V3	MC509	< 1500 mA	< 1000 mA

5.6.2 Power Consumption

The power consumptions of MC509 module in different scenarios are respectively listed in Table 5-7 and Table 5-8.



The power consumption listed in this section is tested when the power supply of the MC509 series module is 3.3 V. Typical values are measured at room temperature, and minimum and maximum values are measured over the entire operating temperature range.

Table 5-7 Averaged standby DC power consumption

Working mode		Max.	Unit
Standby mode	800 MHz	TBD	mA
	1900 MHz	TBD	mA
Data mode	800 MHz	TBD	mA
	1900 MHz	TBD	mA

Table 5-8 DC power consumption (GPS)

Description	Max Test Value	Units	Configuration
GPS location request	TBD	mA	

M NOTE

- Standby current consumption with Sleep mode deactivated-Idle (assumes USB bus is fully suspended during measurements).
- The above values are the average of some test samples.

5.7 Reliability Features

Table 5-9 lists the test conditions and results of the reliability of the MC509 series module.

Table 5-9 Test conditions and results of the reliability of the MC509 series module

Item		Test Condition	Standard	Smaple size	Results
Stress	Low-temperature storage	• Temperature: -40°C±1°C	IEC60068- 2-1 Ab	TBD/group	Visual inspection: TBD
		Operation mode: no power, no packageTest duration: 24 h			Function test: TBD RF specification: TBD



Item		Test Condition	Standard	Smaple size	Results
	High-temperatur e storage	 Temperature: 85°C±1°C Operation mode: no power, no package Test duration: 24h 	IEC60068- 2-2 Bb	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD
	Low-temperature operating	Temperature: -20°C±1°C Operation mode: working with service connected Test duration: 24 h	IEC60068- 2-1 Ae JESD22-A 108-C	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD
	High-temperatur e operating	 Temperature: 60°C±1°C Operation mode: working with service connected Test duration: 24 h 	IEC60068- 2-2 Be JESD22-A 108-C	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD
	Damp heat cycling	 High temperature: 55°C±1°C Low temperature: 25°C±1°C Humidity: 95% ±3% Operation mode: working with service connected Test duration: 6 cycles; 12 h+12 h /cycle 	JESD22-A 101-B	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD
	Temperature shock	 Low temperature: -40°±1°C High temperature: 85°C±1°C Temperature change interval: < 20s Operation mode: no power, no package Test duration: 100 cycles; 15 Min+15 Min/cycle	IEC60068- 2-14 JESD22-A 104-C	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD



Item		Test Condition	Standard	Smaple size	Results
	Salty fog test	 Temperature: 35°C Density of the NaCl solution: 5% ± 1% Operation mode: no power, no package Test duration: Spraying interval: 8 h Duration of exposing the module to the temperature of 35°C: 16 h 	IEC60068- 2-14 JESD22-A 107-B	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD
	Sine vibration	 Frequency range: 5 Hz to 200 Hz Acceleration: 1Grms Frequency scan rate: 0.5 oct/min Operation mode:working with service connected Test duration: 3 axial directions. 2 h for each axial direction. Operation mode: working with service connected 	JESD22-B 103-B	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD
	Shock test	 Half-sine wave shock Peak acceleration: 30Grms Shock duration: 11 ms Operation mode: working with service connected Test duration: 6 axial directions. 3 shocks for each axial direction. Operation mode: working with service connected 	IEC60068- 2-27 JESD-B10 4-C	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD



Item		Test Condition	Standard	Smaple size	Results
	Drop test	 0.8 m in height. Drop the module on the marble terrace with one surface facing downwards, Six surfaces should be tested. Operation mode: no power, no package 	IEC60068- 2-32	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD
Life	High temperature operating life	 Temperature: 60°C±3°C Operation mode: working with service connected Test duration: 168 h, 336 h, 500 h, 1000 h for inspection point 	JESD22-A 108	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD
	High temperature & high humidity	 High temperature: 85°C±3°C Humidity: 85%±3% Operation mode: powered on and no working Test duration: 168h, 336h, 500h, 1000h for inspection point 	JESD22-A 110	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD
	Temperature cycle	 High temperature: 85°C±3°C Low temperature: -40°C±3°C temperature change slope: 6°C/min Operation mode: no power Test duration: 168 h, 336 h, 500 h, 1000 h for inspection point 	JESD22-A 104C	TBD/group	Visual inspection: TBD Function test: TBD RF specification: TBD
NOTE Comments: groups ≥ 2					

5.8 EMC and ESD Features

EMC tests have to be performed on the application as soon as possible to detect any potential problems.



Special attention should be paid to the following:

- Possible harmful emissions radiated by the application to the RF receiver in the receiver band.
- ESD protection is mandatory on all signals which are externally accessible
- Typically, ESD protection is mandatory for the following:
 - RUIM
 - USB
- Length of the RUIM interface lines (preferably <10 cm).
- EMC protection on audio input/output (filters against 900 MHz emissions).
- Ground plane: recommends a common ground plane for analog/digital/RF grounds.
- A metallic or plastic case with conductive paint is recommended, except for the area around the antenna.



The HUAWEI MC509 module does not include any protection against over voltage.



6 Mechanical Specifications

6.1 About This Chapter

This chapter mainly describes mechanical specifications of MC509 module, including:

- Dimensions and Interfaces
- Dimensions of the Mini PCI Express Connector
- Specification Selection for Fasteners
- Antenna Plug
- Thermal Design Guide

6.2 Dimensions and Interfaces

The dimensions of the MC509 module are 50.95 mm (length) $\times 30.4 \text{ mm}$ (width) $\times 3.57 \text{ mm}$ (height). Figure 6-1 shows the dimensions of MC509 module in detail.

Figure 6-1 shows the appearance of the interfaces on the MC509 module.





Figure 6-1 Dimensions of the MC509 module



6.3 Dimensions of the Mini PCI Express Connector

The Mini PCIe Adapter adopts a standard Mini PCI Express connector that has 52 pins and complies with the *PCI Express Mini Card Electromechanical Specification Revision 1.2*.

Figure 6-2 shows a 52-pin Mini PCI Express connector (take the Molex 67910002 as an example).





Figure 6-2 Dimensions of the Mini PCI Express connector

6.4 Specification Selection for Fasteners

6.4.1 Installing the Mini PCIe Adapter on the Main Board


To install the Mini PCle Adapter on the main board, do the following:

Step 1 Insert the Mini PCIe Adapter into the Mini PCI Express connector on the main board.




Step 2 Press downwards to fix the Mini PCle Adapter in the module slot.






Step 3 Use a screwdriver to fix the Mini PCle Adapter on the main board with two screws provided in the Mini PCle Adapter packing box.



Step 4 Insert the connector of the main antenna into the MAIN antenna interface (M) of the Mini PCIe Adapter according to the indication on the label of the Mini PCIe Adapter. Insert the connector of the auxiliary antenna into the AUX antenna interface (A) of the Mini PCIe Adapter and the GPS antenna into the GPS antenna interface (G) of the Mini PCIe Adapter in the same way.






oxdiv note


- Insert the antenna connectors vertically into the antenna interfaces of the Mini PCIe Adapter.
- Do not press or squeeze the antenna cable or damage the connectors. Otherwise, the
 wireless performance of the Mini PCIe Adapter may be reduced or the Mini PCIe Adapter
 cannot work normally.
- Ensure that the antenna cables are routed through the channel in the frame of the PC and do not lay the cables across the raised edges of the frame.

6.4.2 Removing the Mini PCIe Adapter from the Main Board

Step 1 Disconnect the antenna cables from the Mini PCle Adapter. You can lift the connectors using a small screwdriver.




Step 2 Remove the two screws with the screwdriver.




Step 3 Slide backwards the two clips to release the Mini PCIe Adapter from the slot. Then, lift up the Mini PCIe Adapter.






6.5 Antenna Plug

Figure 6-3 Mating the plug



- 1. Align the mating tool or the mating end of the tool over the plug end of the cable assembly.
- 2. Firmly place the tool over the plug until it is secured in the tool.
- 3. Place the plug cable assembly (held in the tool) over the corresponding receptacle.
- 4. Assure that the plug and receptacle are aligned press-down perpendicular to the mounting surface until both connectors are fully mated.
- 5. Remove the mating tool by pulling it up carefully.

Figure 6-4 Unmating the plug






M NOTE

- The extraction tool is recommended.
- Any attempt of unmating by pulling on the cable may result in damage and influence the mechanical/electrical performance.

It is recommended not to apply any pull forces after the bending of the cable, as described in Figure 6-5 .

Figure 6-5 Do not apply any pull forces after the bending of the cable




6.6 Thermal Design Guide


When the module works in the max power condition, the Mini PCIe module has high power consumption (for details, see Table 5-8). To improve the module reliability and stability, focus on the thermal design of the device to speed up heat dissipation.

Take the following heat dissipation measures:

- Do not hollow out the customer PCB.
- Attach the thermal conductive material between the Mini PCIe and the customer PCB. The recommended thermal conductivity of the thermal conductive material is 1.0 W/m-k or higher (recommended manufacturers: Laird and Bergquist). The dimensions (W x D) of the thermal conductive material are 38 mm x 28 mm (1.50 in. x 1.10 in.), and its height depends on the height of the Mini PCIe connector you use and the method for installing the Mini PCIe. When deciding the height of the thermal conductive material, you are advised to obey the following rule: After the Mini PCIe is fastened to the customer PCB, the compression amount of the thermal conductive material accounts for 15% to 30% of the thermal conductive material size. For example, if you use a connector shown in the following figure and install the Mini PCIe like this, the recommended height of the thermal conductive material is 1.8 mm (0.07 in.).



 On the customer PCB, reserve two metal screw holes, which are connected to the PCB ground plane. When installing the Mini PCle, use two metal screws to fasten the Mini PCle to the customer PCB. See the following figure.



- Ensure that the air flow around the Mini PCle is sufficient.
- Try not to place any component in the Mini PCle's projection region on the customer PCB. Do not place components with 1.5 W or higher power consumption or heat sensitive components (such as crystals) near the Mini PCle.
- Use a large customer PCB. The recommended size (W x D) is 80 mm x 80 mm (3.15 in. x 3.15 in.).
- Apply copper to the region for attaching the thermal conductive material to the customer PCB. Try to use the continuous ground plane design on the customer PCB, and each ground plane must be connected through holes. Therefore, reserve holes as many as possible.

M NOTE

If you do not take the preceding heat dissipation measures, the overheat protection mechanism is triggered due to overheated Mini PCIe and the network connection is terminated when the Mini PCIe keeps working in enclosed space with a 60° C temperature and the max power condition for a period of time. You can resume the network connection only after the temperature drops.



7 Certifications

7.1 About This Chapter

This chapter gives a general description of certifications of MC509 module.

7.2 Certifications

■ NOTE

The certification of MC509 module is testing now. Table 7-1 shows certifications the MC509 module will be implemented. For more demands, please contact us for more details about this information.

Table 7-1 Product Certifications

Certification	Model name		
	MC509	MC509-a	
FCC	V	-	
RoHS	\checkmark	-	
CCC	\checkmark	\checkmark	

■ NOTE

The model of MC509-a module for CCC certification is HUAWEI MC509.



8 Safety Information

Read the safety information carefully to ensure the correct and safe use of your wireless device. Applicable safety information must be observed.

8.1 Interference

Power off your wireless device if using the device is prohibited. Do not use the wireless device when it causes danger or interference with electric devices.

8.2 Medical Device

- Power off your wireless device and follow the rules and regulations set forth by the hospitals and health care facilities.
- Some wireless devices may affect the performance of the hearing aids. For any such problems, consult your service provider.
- Pacemaker manufacturers recommend that a minimum distance of 15 cm be maintained between the wireless device and a pacemaker to prevent potential interference with the pacemaker. If you are using an electronic medical device, consult the doctor or device manufacturer to confirm whether the radio wave affects the operation of this device.

8.3 Area with Inflammables and Explosives

To prevent explosions and fires in areas that are stored with inflammable and explosive devices, power off your wireless device and observe the rules. Areas stored with inflammables and explosives include but are not limited to the following:

- Gas station
- Fuel depot (such as the bunk below the deck of a ship)
- Container/Vehicle for storing or transporting fuels or chemical products
- Area where the air contains chemical substances and particles (such as granule, dust, or metal powder)
- Area indicated with the "Explosives" sign



- Area indicated with the "Power off bi-direction wireless equipment" sign
- Area where you are generally suggested to stop the engine of a vehicle

8.4 Traffic Security

- Observe local laws and regulations while using the wireless device. To prevent accidents, do not use your wireless device while driving.
- RF signals may affect electronic systems of motor vehicles. For more information, consult the vehicle manufacturer.
- In a motor vehicle, do not place the wireless device over the air bag or in the air bag deployment area. Otherwise, the wireless device may hurt you owing to the strong force when the air bag inflates.

8.5 Airline Security

Observe the rules and regulations of airline companies. When boarding or approaching a plane, power off your wireless device. Otherwise, the radio signal of the wireless device may interfere with the plane control signals.

8.6 Safety of Children

Do not allow children to use the wireless device without guidance. Small and sharp components of the wireless device may cause danger to children or cause suffocation if children swallow the components.

8.7 Environment Protection

Observe the local regulations regarding the disposal of your packaging materials, used wireless device and accessories, and promote their recycling.

8.8 WEEE Approval

The wireless device is in compliance with the essential requirements and other relevant provisions of the Waste Electrical and Electronic Equipment Directive 2012/19/EU (WEEE Directive).

8.9 RoHS Approval

The wireless device is in compliance with the restriction of the use of certain hazardous substances in electrical and electronic equipment Directive 2011/65/EU (RoHS Directive).



8.10 Laws and Regulations Observance

Observe laws and regulations when using your wireless device. Respect the privacy and legal rights of the others.

8.11 Care and Maintenance

It is normal that your wireless device gets hot when you use or charge it. Before you clean or maintain the wireless device, stop all applications and power off the wireless device.

- Use your wireless device and accessories with care and in clean environment.
 Keep the wireless device from a fire or a lit cigarette.
- Protect your wireless device and accessories from water and vapour and keep them dry.
- Do not drop, throw or bend your wireless device.
- Clean your wireless device with a piece of damp and soft antistatic cloth. Do not use any chemical agents (such as alcohol and benzene), chemical detergent, or powder to clean it.
- Do not leave your wireless device and accessories in a place with a considerably low or high temperature.
- Use only accessories of the wireless device approved by the manufacture.
 Contact the authorized service center for any abnormity of the wireless device or accessories.
- Do not dismantle the wireless device or accessories. Otherwise, the wireless device and accessories are not covered by the warranty.
- The device should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

8.12 Emergency Call

This wireless device functions through receiving and transmitting radio signals. Therefore, the connection cannot be guaranteed in all conditions. In an emergency, you should not rely solely on the wireless device for essential communications.

8.13 Regulatory Information

The following approvals and notices apply in specific regions as noted.

8.13.1 CE Approval (European Union)

The wireless device is approved to be used in the member states of the EU. The wireless device is in compliance with the essential requirements and other relevant provisions of the Radio and Telecommunications Terminal Equipment Directive 1999/5/EC (R&TTE Directive).



8.13.2 FCC Statement

Federal Communications Commission Notice (United States): Before a wireless device model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Warning: Changes or modifications made to this equipment not expressly approved by HUAWEI may void the FCC authorization to operate this equipment.





9

Appendix A Circuit of Typical Interface





10 Appendix B Acronyms and Abbreviations

Acronym or Abbreviation	Expansion
3GPP	Third Generation Partnership Project
8PSK	8 Phase Shift Keying
AUX	Auxiliary
BER	Bit Error Rate
BIOS	Basic Input Output System
BLER	Block Error Rate
CCC	China Compulsory Certification
CE	European Conformity
CS	Coding Scheme
CSD	Circuit Switched Data
DC	Direct Current
DCE	Data Communication Equipment
EMC	Electromagnetic Compatibility
ESD	Electrostatic Discharge
EU	European Union
FCC	Federal Communications Commission
GPIO	General-purpose I/O
ISO	International Standards Organization
LCP	Liquid Crystal Polyester
LDO	Low-Dropout



Acronym or Abbreviation	Expansion
LED	Light-Emitting Diode
LGA	Land Grid Array
MCP	Multi-chip Package
PCB	Printed Circuit Board
RF	Radio Frequency
RoHS	Restriction of the Use of Certain Hazardous Substances
TBD	To Be Determined
TTFF	Time to First Fix
TVS	Transient Voltage Suppressor
UMTS	Universal Mobile Telecommunications System
USB	Universal Serial Bus
RUIM	Removable User Identity Module
VSWR	Voltage Standing Wave Ratio
WEEE	Waste Electrical and Electronic Equipment